


GPS: The process GPS routine allows for reduction of GPS records that reside in a raw (*.RW5) file from latitude, longitude and WGS84 Ellipsoid Height to State Plane or local coordinates. When selected, the GPS Settings dialog will appear as shown below.



The image shows a Windows-style dialog box titled "Process Options". It contains several sections with radio buttons and dropdown menus. The "Projection Type" section has three options: "State Plane 27" (selected), "State Plane 83", and "UTM". The "Zone:" label is followed by a dropdown menu showing "UT South". The "Transformation" section has two options: "Rigid Body (No Scale)" and "Plane Similarity" (selected). The "One Point Alignment Azimuth" section has two options: "Geodetic" and "State Plane Grid" (selected). The "Geoid To Apply" label is followed by a dropdown menu showing "USA (Geoid03)". The "Units" section has three options: "Metric", "US Feet" (selected), and "Int'l Feet". The "Scale Factor" label is followed by a text box containing "1.000000000". At the bottom are "OK" and "Cancel" buttons.

GPS>ProjectionType:

Defines the datum coordinate system to be used for converting the latitude, Longitude and WGS84 Ellipsoid height collected from the GPS receiver into Cartesian coordinates. The supported projection types are State Plane 83, State Plane 27, UTM, Lat/Long, Great Britain-OSGB36, Australia, New Zealand-NZGD2000, New Zealand-NZGD49, and France NTF-GR3DF97A. The supported geoids include: Geoid99 (USA), Geoid03 (USA), EGM96 (World), SGM02 (Britain).

GPS>Zone: for State Plane projections, you must select the correct state zone that you are working in. For UTM, the Automatic Zone option will have the program automatically use the program automatically use the correct UTM zone for your location. Otherwise for UTM, you can manually set a specific UTM zone. This manual option applies to working on the border between zones and you want to force the program to always use one of those zones.

GPS>Use Alignment File For Localization: With this option toggle on, a prompt for the Alignment File to Process will be displayed. This file is typically created by SurvCE (Carlson's Data Collection System) using the Localization routine or by Carlson Field Using the Align to Local Coordinates routine. This file (*.DAT or *.LOC) contains the parameters to transform the derived State Plane coordinates to the defined local coordinates.

At the end of the process, the coordinates will be written to the current coordinate (*.crd) file and a report will be presented in the Carlson editor for saving or printing purposes.

GPS>Transformation: The transformation in the align Local Coordinates command can either be by plane similarity or rigid body methods. The difference is that the rigid body method does a transformation with a translation and rotation and without a scale. The plane similarity does a rotation, translation and scale. This option only applies when two or more points are used in the Localization routine in SurvCE.

GPS>One Point Alignment Azimuth: This option applies to the rotation when using one point in Align Local Coordinates or the Localization routine in SurvCE. For this alignment method, the state plane coordinate is translated to the local coordinate. Then the rotation can use either the state plane grid or the geodetic as north. No scale is applied in this transformation. The state plane and geodetic true north diverge slightly in the east and west edges of the state plane zone. This option allows you to choose which north to use.

GPS>Project Scale Factor: For most applications, the Scale Factor should be set to 1.0. The scale factor represents the "combined" grid/elevation factor that reduces ground distances to grid. After converting the LAT/LONG from the GPS records to state plane coordinates and applying the coordinate alignment (Localization) file, the Project Scale Factor is applied as the final adjustment to the coordinates. This adjustment is used on the X, Y, and not the Z. The Project Scale Factor is applied by dividing the distance between the coordinate and a base point by the Project Scale Factor. The coordinate is then set by starting from the base point and moving in the direction to the coordinate for the adjusted distance. The base point is the first point in the alignment (Localization) file. If there are no points specified in the alignment file, then 0,0 is used as the base point. If using an alignment file (Localization File) this value will be automatically calculated and displayed. Manual entry of a scale factor is also permitted and is often used with the Two Point Alignment Method when a scale factor is known.

GPS>Geoid to Apply: The supported geoids include: Geoid99 (USA), Geoid03 (USA), EGM96 (World), GDA94 (Australia), CGG2000, HT 2.0, HT HT 1.01 (Canada) and SGM02 (Britain).

This option will account for the geoid undulation in determining the orthometric elevation of the measurement. The definition of the geoid model as currently adopted by the national Geodetic survey is the equipotential surface of the Earth's gravity field which best fits, in a least squares sense, global mean sea level. Orthometric elevation measurements are used in survey calculations. In order to convert ellipsoid heights (He) as measured by GPS into orthometric elevations (E0), you must provide for a correction between the GPS-measured ellipsoid (reference ellipsoid) and a constant level gravitational surface, the geoid. This correction is the geoid undulation (Ug). The formula is $He = E0 + Ug$.

Carlson applies the Geoid model by subtracting the Geoid undulation from the GPS elevation. The resulting elevation is then used and displayed. In practice, the Geoid model is most applicable to two types of alignment scenarios. One of these types is when setting up the base over a known point and having no alignment control points. The other is when there is one alignment control point. When using multiple alignment control points, the Geoid model is not as important because Carlson can model the elevation difference which can generally pick up the local Geoid undulation.

GPS>Units: Coordinates can be reduced into one of three available units, Metric, US Feet or International Feet.