

---

**Install SurvCE Version 2.50 using the steps below:****1) Download SurvCE 2.50 using the link below:**

a. Click the link below:

<http://tiny.cc/survce>b. Make sure the "Select Build" at the top of the WebPage is set to **2.50 or higher**

c. Then select the correct download in the list that matches up with your Data Collector

**2) PLUG in the USB cable** from your Data Collector to your Desktop or Laptop computer to get connected with ActiveSync.*If you have Windows XP and need to install ActiveSync click the link below. After it downloads click "Run" and then Follow the On-Screen prompts to install it:*<http://tiny.cc/async45>*For Windows Vista or Windows 7 computers without Windows Mobile Device Center click the link below:*<http://tiny.cc/wmdevctr>**3) On the Data Collector** - Tap File & Exit to make sure you exit out of SurvCE before the Install if you are already running a previous version of SurvCE.**4) On the Desktop PC** - Double click the SurvCE file that you downloaded in Step 1. Click Run / Next / Click I Accept / Click Install / Click yes to Re-Install.5) Let the status bar go across on the Desktop PC and **Click OK** when it prompts "Please Check your Mobile Device" then **Click Finish** on the Desktop PC.**6) On the Data Collector - Tap OK** if it asks you to "Remove the Previous Version"7) **Tap "Install"** in the bottom left on the Data Collector to install SurvCE8) Once the Status Bar finishes on the data collector it will say "Carlson Software was successfully installed" --- you can **Tap OK** in the upper right

9) To verify that you are now on the latest version --- Open SurvCE / tap the Equip Tab / Tap About SurvCE: Check to see that the version and date on the top match what you downloaded {i.e. - Version 2.50} tap Close after you check your version.

**10) This completes the upgrade / install of SurvCE**