

If you were previously using SurvCE Version 1.6 or 1.5 and you've upgraded to SurvCE 2.5 or higher the table below will help you find commonly used routines in the new version

Feature Name	Old SurvCE 1.6	NEW SurvCE 2.0
Text Mode in Store Points	Text button in the upper left	Tap Helmet Icon in upper left to switch between Graph & Text OR use Alt-Y on the Keyboard
Raw Data	Cogo / Process Raw File	File / Raw Data
Configure Reading	File / Configure Reading	Equip / Configure
Comm Setup	Equip / Comm Setup	Inside one of the top 3 Choices in Equip tab (i.e. - Equip / "Total Station" / Comms = same for GPS Base or GPS Rover)
Total Station Settings	Equip / Settings	Equip / Total Station / Settings
Units settings	File / Job Settings / Units	File / Job Settings / System & Format
Geoids and Projections	File / Job Settings / GPS	Equip / Localization / System, TS, GPS
Instrument Profiles	Profile Icon in Upper Right	Saving and Loading Instrument profiles has been moved inside one of the top 3 choices in the Equip tab: Total Station, GPS Base and GPS Rover --- use the Save and Load buttons at the Bottom of the "Current tab"

Two Major 2.0 Features:

- 1) Equip / Configure / Prompt for Total Station Setup = Check the box if you'd like it to act like 1.6x
- 2) Equip / Configure / 3D Mode = Uncheck this for using 2D mode with Total stations