

Zeiss DiNi Electronic Level, Rec E Data Format (Zeiss DiNi) Quick Start Guide

Author: Adam Messer
Last Updated: January 24, 2007

Set the following on the Zeiss Level:

- 1) Press <Menu> on the level.
- 2) From Menu Option 4 (Set Rec. Param.).
- 3) Menu Option 1 (Recording of Data).
- 4) Set Record to V.24.
- 5) Set Rod Readings to R-M.
- 6) Menu Option 2 (Parameter Settings).
- 7) Set Format to Rec E.
- 8) Set Protoc to Xon/Xoff.
- 9) Set Baudrate to 9600.
- 10) Set Parity to Odd.
- 11) Set StopBits to 2.
- 12) Set Line Feed to Yes.