



Photograph Gallery

In SurvCE multiple photographs can be associated with a point or line. In the Photograph Gallery a photograph can be captured or selected.

Take a Picture

To take a picture click the Capture button to launch the camera program. This will use the camera on the data collector.

Select a Picture

Browse existing photograph by clicking on the *Select* button. These photographs will be copied to the job Photograph folder and linked to the point.



Camera Program

To display your cameras options and features pick the menu button. The camera options shown are for the Nautiz X7.



To take a picture press the return button on the data collector.

To close and save the photograph click OK on the screen or press OK on the data collector.

<u>Do not use the Camera button</u>. This will open a Camera program not linked to SurvCE.